
JLG Cassette cover installation manual

■ Follow the details to install the external cover correctly.

- Read the installation manual carefully before installing the cover.
- To prevent the exterior of the cover from being scratched or become dirty during the assembly, always put a clean sheet on the floor.
- Always use the screw included in the product. (If you use other screws, it can damage the product.)


■ The purpose of this external cover is to prevent the indoor unit from being exposed externally.

• Use this when install the cassette air conditioner on the ceiling without any finishing.





■ The characteristics of this external cover are as follows.

- 1. The height of the cover can be adjusted according to the height of the product. (Refer to top picture)
- 2. Cover on the piping side can be detached.





■ This product is composed of the following components.






Screw (32 units)	
and G	







P/No.:3828A20128R

■ Installation order

