



Internal Use Only

<http://biz.lgservice.com>

AHU EEV KIT

SVC MANUAL(Exploded View)


MODEL : PRLK048A0
PRLK096A0

CAUTION

Before Servicing the unit, read the safety precautions in General SVC manual.
Only for authorized service personnel.

Exploded View and Replacement Parts List


Model : PRLK048A0



| LOCATION NO. | DESCRIPTION | PART NO. | QTY |
|--------------|--------------------------|-------------|-----|
| 55211G | Tube Assembly, Expansion | AJR55715601 | 1 |

Exploded View and Replacement Parts List

Model : PRLK096A0



| LOCATION NO. | DESCRIPTION | PART NO. | QTY |
|--------------|--------------------------|-------------|-----|
| 55211G | Tube Assembly, Expansion | AJR55715602 | 1 |



P/NO : MFL67103106

JULY, 2012